

## MAIN SPRING ADJUSTMENT

The speed of a clay can be adjusted by tightening or loosening the main spring (1). Adjust the spring tension to your needs, remembering that the more spring is tightened, the higher the speed of a clay.

To set the desired spring tension, loosen the locknut (2), then tighten or loosen the three-arm knob (3) and secure with the locknut (2).

**VERY IMPORTANT:** It is essential that at minimum spring tension, its coils do not touch each other. Failure to do so may result in damage to the throwing machine.

