

## SPRING ADJUSTMENT

The throwing distance can be adjusted by tightening or loosening the main spring (1). Adjust the spring tension that is appropriate for your needs, remembering that the more the spring is stretched, the greater the speed of the clay and its flying distance.

To set desired spring tension, loosen the jam nut (3), then tighten or loosen the nut (2) and lock with jam nut (3).

**NOTE: It is necessary that with minimal spring tension, the coils should not touch each other at all times. Failure to do so may damage the throwing machine.**

